



AC Powered TS1000 Installation Pictures

(Core Drill and Saw Cut)

City of Manteca, CA

11/07

AC Powered TS1000 Installation Pictures



1. Fixture layout



2. Core Drill



3. Saw Cut



4. Drainage



5. Mounting Jig Setup



6. Base Can Alignment

AC Powered TS1000 Installation Pictures



7. Base Can in Concrete



8. Plywood Protective Cover



9. Fixtures Placed In Base Cans