



SafePace Cloud

Control your signs, access data and adjust settings from anywhere, anytime with remote access via SafePace Cloud

General Description



SafePace Cloud offers you the convenience to connect to and control your signs from any Internet connected device. With detailed reporting, customized alerts, and real-time data, you can see stats for each sign, change settings, check batteries and download data without spending time traveling to sign locations. SafePace Cloud is an investment in the performance and success of your SafePace speed signs.

Benefits

- View real-time sign data
- Access all sign stats from one location
- Download detailed traffic data and reports
- Set up customized alerts
- Change settings and parameters
- Cut down on workforce hours
- Compatible with all SafePace signs

Features

- **Better Sign Management:** Manage all your signs from one screen, accessing more granular data simply and quickly. One-click scheduling lets you update signs individually or simultaneously.
- **Data & Reporting:** View at-a-glance updates, access real-time data, see data overview or details, and generate reports to analyze and improve your traffic management program.
- **Mapping:** View all your signs from one screen using our interactive mapping tool. Zoom in on individual signs to access detailed stats and/or update settings.
- **Zero Footprint:** No software install, no hardware required, access a wealth of intelligent traffic data from anywhere, anytime.
- **Alerts:** Set up automated alerts for speeding thresholds, low battery, or tampering. Receive updates via email or text.
- **Improved Efficiency:** Improve workforce efficiency and optimize resources by reducing travel time required for sign management.



Cloud Based
Secure, remote access for simple-to-use sign management from anywhere with Internet.



Real-Time Data
See live performance data updated every five minutes.



User Friendly
Streamlined, easy-to-use interface.



Comprehensive Reporting
Use data to generate detailed reports you can use to better improve safety on your roads.



Mapping Tool
Map unlimited sign locations and create and apply parameters for each. Update sign location whenever a sign or trailer is moved.



One-Screen Management
Manage alerts, messages, and display settings all from one screen.



One-Click Scheduling
One click lets you schedule and program multiple signs simultaneously.



Complete Control
Manage all aspects of sign configuration including schedules, messages, blinking limit, strobe limit, and display range.



Scheduling
Display settings can be constant or schedule based. Signs and beacons can be scheduled based on daily, weekly, and holiday schedules.



At-a-Glance Update
Statistics snapshot provides at-a-glance data updates including vehicle count, 85th percentile, and maximum and minimum speed.



Real-Time Alerts
Receive email notification for alerts such as high or low speed or when batteries are low.



SafePace Compatible
Compatible for use with all SafePace radar speed signs.

+1.888.446.9255 USA
+1.916.394.9884 Worldwide
+1.916.394.2809 Fax

xwalk.com
sales@xwalk.com

Traffic Safety Corp., 2708 47th Ave.
Sacramento, CA, 95822, USA